


## [Network Camera Display - Update Information]

Displaying network camera image on the V9 to grasp current status of the factory floor in real time!

What is network camera display function?

You can connect network cameras to V9 via Ethernet to display captured images on it.





Ethernet

It is useful for various applications such as monitoring a clean room!

n!

Network cameras from Axis, Panasonic and BANNER are supported.

Manufacturer		Туре	Protocol
Axis	·All models	MOTION-JPEG (motion picture)	HTTP protocol communication (TCP/IP)
Panasonic	•BB series •BL series		
BANNER	·PresencePLUS P4 OMNI	Bitmap (still image)	Dedicated protocol

#### Panasonic BB series: verified models



Which BB series should I select to connect it to V9 without fail?

Are you still thinking which camera you are going to use?
Try these verified models!

Panasonic BB-HCM580 BL-C111

> BB-SW172A BB-ST165A

**BB-SP104W** 

It is reliable because they are all verified at Hakko!


Newly verified\*



\*To be included in the next upgrade.




### Caution: When connecting Axis network camera



# Some Axis network cameras have the following [HTTP/RTSP Password Settings] option.

e.g.) Setting for M3104-LVE





All the V9 series support network camera because they all have on-board LAN port! Please take this opportunity to try this feature!

## Hakko Electronics Co., Ltd.

Overseas Sales Dept.
TEL: +81-76-274-2144 FAX: +81-76-274-5136
http://monitouch.fujielectric.com/