

# TELLUS USB License Key is Available!

**Issue No. 2** 2008

### **Added the Form of License Authentication**

In addition to the existing form of license by PCID, the license authentication by USB is now available.

### SOFT MONITOUCH

# TELLUS and V-Server


"TELLUS and V-Server" is capable to realize the remote maintenance by remotely connecting the office PC and the on-site Monitouch.



On-site Monitouch data can be monitored from the office.




Real-time on-site data Collection and storage.




# Remote monitoring is realized by easy structure!

- LAN access




- Internet access



- WAN access



- Connection via phone line



# More user-friendliness!



Usable right form the first day of your purchase.

By inserting the "USB License Key" in the USB port of your PC, it can be used as the qualified product as soon as you receive the product without any restrictions.



No need to worry about the unexpected failure of your PC.

It is directly usable with the alternative PC only by inserting the USB License Key in it, even when your PC has unexpectedly crashed.

All brand names and product names in above are trademarks or registered trademarks of their respective companies.

# MONITOUCH PLE EXPRESS

# **Usage**

- 1) Install TELLUS on your PC.
- 2) Insert the "USB License Key" in the USB port of your PC.
- 3) Start TELLUS or V-Server.


# USB License Key


# **Type of License**

The license authentication is required to use SOFT MONITOUCH TELLUS/V-Server. One license qualifies a license for one PC. The following licenses are available in response to the functions.


USB License Key	
TELLUS-HMI USB Key	1
TELLUS-Remote USB Key	3
TELLUS & V-Server USB Key	3

Password Authentication	
TELLUS-HMI	1
TELLUS-Remote	3
TELLUS & V-Server	3
V-Server	4









# Free version upgrade of TELLUS and V-Server



TELLUS and V-Server (updated version) can be downloaded from the following website.

Website:

http://www.hakko-elec.co.jp/en/download/03tellus/index.html

