

# MONITOUCH EXPRESS

### V9 series Alarm Function - Part 1 -

Issue No. 51 August 2014


Various features have been added for Alarm Function.

- Scrolling Messages : Alarm messages are automatically displayed on the screen.
- Customization of Display Content: You can set ruled lines, display items or display order freely.
- Scroll Function : By scrolling display area, items even out of the area can be confirmed.

# **Scrolling Messages**

When an error occurs, the corresponding alarm message is automatically displayed on the unit regardless of the currently displayed screen.

By giving operators an instant notice, it can help to analyze the cause of the error and to perform the recovery measures quickly!!




[No error occurred]

[While error is occurring]

#### Scroll tool display

You are able to pause/fast-forward the messages and to change the display position on the unit.


No change in program is needed!!



# **Customization of Display Content**

More options are available: ruled lines, display item selection, and display order. You can also specify the title for each column.

Customize the alarm display parts as you prefer to make it "easy to grasp".






## Scroll Function

Scroll function for items to display

Even if the display area is not big enough to show all items, you can just scroll the display area to confirm them all.

It is not necessary to change the layout or to create another screen.





Auto scrolling of alarm messages

The long messages which cannot fit the display width are scrolled automatically. No modification to shorten the messages is needed.

