

<Reduction of Work Hours for Screen Program Configuration> Simplify Configuration Tasks by Item Select Function of Entry Targets!


Data Display - Entry Target: Item Select Finction (V9/X1) Ver. 6.1.3.0 or later

What is the item select function?

The item select function is for **moving the cursor to a specific entry target** such as when entering numeric values.





There are **three methods** for moving the cursor.




CL-003

CL-004







FO Fuji Electric MONITOUCH EXPRESS



Configuration is made easy from V-SFT Ver. 6.1.3.0 or later!



Not only is this setting convenient for when configuring a new screen program, it is also useful when <u>modifying an existing screen program</u>!



Hakko Electronics Co., Ltd.